


NDIR CO₂ Gas Sensor Calibration

This calibration procedure described in this document applies to all NDIR Carbon Dioxide (CO₂) sensors (both dual channel and single channel) manufactured by SemeaTech.

1. Baud rate: 19200 bps, 8 bytes, first byte is stop, no check byte

2. CO₂ concentration READ and RETURN in HEX code

ASCII format for automatic upload CO₂ concentration:



 $0x20 \quad 0x20 \quad 0x31 \quad 0x32 \quad 0x33 \quad 0x34 \quad 0x35 \quad 0x20 \quad 0x70 \quad 0x70 \quad 0x6d$

3. Zeroing (Zero Calibration) using Nitrogen (N2)

STA	Co	mmand	Ch	END	
0x23	0x57	0x31	0x36	0x36	0x21

STA:0x23, and 0x23 means START;

Command: 0x57, and 0x57 means WRITING;

Command: 0x31, and 0X31 means Zeroing in N₂;

CheckSum: 0x36, and 0x36 is the CheckSum that is the ASCII code of a sum of XOR of all data except STA and END;

END: 0x21, and 0x21 means CLOSE.

Caution: The command of zero calibration should be sent after the module stays in N₂ for 5 minutes.

4. SPAN Calibration

STA	Command		Gas Cctn					CheckSum		END
0x23	0x57	0x32	GC1	GC2	GC3	GC4	GC5	Н	L	0x21

STA: 0x23, and 0x23 means START;

Command: 0x57, and 0x57 means WRITE;

Command: 0x32, and 0x32 means SPAN calibration;

Gas Cctn: the concentration of the span CO_2 gas. The value of concentration should be a percentage of the full scale. For example, if the span CO_2 gas is 500ppm, and the full scale of the sensor is 5,000 ppm, it turns out Gas Cctn=500/5000=10%. In this scenario the command should be:

STA	Command		ommand Gas Cctn					CheckSum		END	I
0x23	0x57	0x32	0x30	0x30	0x30	0x31	0x30	0x35	0x34	0x21	I

Here, CheckSum 0x35 and 0x34 is the CheckSum that is the ASCII code of a sum of the XOR of all data except STA and END. END 0x21 means CLOSE.



Caution: The command of SPAN calibration should be sent after the module stays in the span gas for 5 min.

5. Clean Air Calibration

Clean air calibration should be done only when the output is quite different from the true value. There are two ways to calibrate in clean air, manual calibration and CW calibration.

5.1 Manual calibration

To perform manual calibration, set the value to default value at 420 ppm. Connect PIN9 and PIN12 together and then wait for more than 5 seconds. After that, the display will show 420.

5.2 Manual calibration

CW calibration is a single-point calibration. The CO_2 concentration can be randomly set. In general CO_2 concentration of outside fresh air is between 390 ppm and 450 ppm, we pick 400 ppm to conduct a single point calibration as an example. The command consists of 16 numbers in the format:

235735 3X3X3X3X3X 3Y3Y 21

Here,

235735 is start of command, in which 23 means Command, 57 means Write, and 35 means Clean Air Calibration;

21 is the end of this command;

XXXXX in 3X3X3X3X3X means the optional concentration. The unit is ppm. For example, if the chosen CO₂ concentration is 517 ppm, it will be written as 3030353137. If it is 89,321 ppm, it will be written as 3839333231.

YY in 3Y3Y is XOR of 57353X3X3X3X3X. For example, if XOR of 350ppm is 54, 3Y3Y should be 3534.

Here comes more examples:

2357353030333030353121 means 300 ppm 2357353030333530353421 means 350 ppm 2357353030333830353921 means 380 ppm 2357353030343030353621 means 400 ppm 2357353030343230353421 means 420 ppm 2357353030343530363321 means 450 ppm 2357353030363030353421 means 600 ppm 2357353031303030353321 means 1,000 ppm 2357353031353030353621 means 1,500 ppm

Caution: For better accuracy, do not breath closely to the air inlet of the sensor during calibration.